

## Laboratory Room Single Duct Supply Air Terminal



**Figure 1. Laboratory Room Single Duct Supply Air Terminal.**

The Laboratory Room Single Duct Supply Air Terminal is an industrial-grade, easy-to-install pre-packaged airflow measurement and control terminal unit. The Laboratory Room Single Duct Supply Air Terminal is a round inlet, rectangular outlet, one piece insulated and lined terminal that provides cooling only or cooling with hot water reheat. When used with the Laboratory Room Controller, it provides fast acting, stable and precise laboratory supply airflow control over the entire range of room airflow requirements.

Measurement of airflow is accomplished by four quadrant sensing technology to achieve measurement accuracy of 3% of actual flow (sensor only) when tested in accordance with AMCA 610. Airflow control is achieved utilizing a round single blade damper mounted on a zinc plated steel shaft with polyethylene bushings and mechanical stops. Construction is 22 gauge-galvanized steel, including the casing and damper.

### Features

- Eight standard sizes with airflow capacities from 35 to 8530 cfm; others are also available.
- Four quadrant airflow sensors with multi-point, center averaging and signal amplification.
- Low radiated and discharge sound levels.
- 22 gauge casing with slip and drive discharge connection.
- Solid zinc plated steel damper shaft on self lubricating polyethylene bushings for fast acting control and maintenance free operation.
- Low non-recoverable static pressure loss.
- Round, beaded inlet collar accepts nominal flexible or rigid duct (size 18 has rectangular inlet).
- Internal insulation 3/4-inch fiber-free foam which meets requirements of NFPA 90A and UL181. Closed cell structure foam allows for disinfecting and hand washing with detergents and water.
- Meets mechanical standards UL 181, NFPA 90A, ASTM E84, UL 723 and bacteria standard ASTM C665.
- Ultra-low leakage, damper and casing.
- Up to four rows of hot water reheat coils.
- Meets equipment requirements of ASHRAE 62.1 Sec. 5.
- Clean, sealed shipping bags available for LEED IEQ projects.
- Lab DXR (IP) control packages available

## Description

The Single Duct Supply Terminal consists of the following components (see Figures 2 through 6).

- Galvanized steel round inlet duct, damper blade in sizes from 4" (10.2 cm) to 16" (40.6 cm) diameter; size 18 unit has a rectangular 16 x 24 inlet and two 16" (40.6 cm) diameter dampers.
- Four quadrant airflow measurement sensor.
- Rectangular, lined and insulated casing with slip and drive outlet connections.
- Factory-mounted controls options.
- Electronic damper control – high speed or standard speed

## Specifications

### Materials (within air stream) – Standard

Duct Casing	22 gauge galvanized steel with mechanically locked and sealed seam
Airflow Sensor	PVC sensing arms and center manifold with galvanized steel frame
Damper Blade	22 gauge, galvanized steel single damper with Volara foam gasket
Damper Shaft	1/2-inch (1.27 cm) diameter, zinc-plated steel. Shaft end marked with the damper blade position
Damper Bushing	Self lubricating polyethylene
Case Insulation	3/4-fiber free foam. Density 1.5 lb/ft <sup>3</sup>  Meets NFPA 90A UL181  Flame Spread rating <25 Smoke Developed rating < 50  Meets ASTM E84 UL 723, bacteria stand. ASTM C665

Hot water reheat coils (optional)	22 gauge, galvanized casing, Aluminum sine wave fins (thickness 0.0045") Copper tubes, 0.016" wall  Meets ARI 410
-----------------------------------	--

Dimensions	
Sizes	See Figures 4, 5, 6 and 7
Weight	19 to 63 lbs. (8.6 to 28.6 kg)

Materials (outside air stream) - Standard	
Control Enclosure	18 gauge two piece galvanized steel
Pneumatic Tubing	UL rated 94 V-2 fire retardant polyethylene
Pneumatic Fittings	Brass, dual barbed

Airflow Measurement	
Sensor Type	Four quadrant, with 12 sensing points, center averaging, and signal amplification

Accuracy	
Flow Measurement	±3% of actual flow @ listed ranges (Sensor only, per AMCA 610)
Installation Requirements	Rigid duct of the same diameter 1 x duct diameters upstream from the sensor, or taper angle less than 30 degrees

Airflow Control	
Damper Blade	Round, sealing single blade with 90 degree control with two mechanical stops

Non-Recoverable Terminal	
Pressure Loss	See Table 2

Environmental	
Operating Temperature/% rh	40 to 120°F (4 to 50°C) 0 to 95% non-condensing
Storage Temperature/% rh	-10 to 150°F (-23 to 65°C) 0 to 95% non-condensing




Figure 2. Single Duct Supply Air Terminal Components with Reheat (cut view).




Figure 3. High Capacity Single Duct Supply Air Terminal Components.

### Single Duct Supply Air Terminal Components (inlet view).

## Ordering Information

Part numbers are created based on the selections you choose. There are no spaces or dashes in the SAP part number.

**NOTE:** Not all combinations or configurations will yield a valid part number in SAP.

**Sample Part Number:** LGS0575R14DBBO

Model Number	Control Package Number	Shaft/Coil Orientation	Inlet (Duct) Size	Reheat Coil Configuration	Lining	Construction	(Custom) Integral Attenuator
LGS	O575	R	14	DB	B	O	—
Laboratory Room Single Duct Supply Air Terminal	This package provides an actuator, a transducer, a flow transmitter, and a controller.	Shaft and coil are on opposite sides.	The inlet (or duct) size is 14 inches.	4 row, left	Fiber-free foam	Low leakage	Not included in this sample part number.

To create an orderable part number that can be entered in SAP, complete the following steps:

1. Begin with the Model Number, **LGS**.
2. Select a Control Package number from the following table and append it to the Model Number. Once you have completed this step, proceed to Step 3.

### Standard

Control Package	Includes the following Control Components:			
	Actuator Part Number	Transducer Part Number	Flow Transmitter Part Number	Controller Part Number
E000*	—	—	—	—
G000	—	—	—	—
G514	GDE131.1P	—	550-819B	—
G516	GMA131.1P	—	550-819B	—
G575	GNP191.1P	—	550-819B	—
G872	GNP191.1P	—	590-780	—
G875	GNP191.1P	—	—	—
G914	GDE131.1P	—	—	—
G915	GDE161.1P	—	590-780	—
G916	GMA131.1P	—	—	—
G917	GMA161.1P	—	590-780	—
<b>O514</b>	<b>GDE131.1P</b>	—	550-819B	550-767FN
O516	GMA131.1P	—	550-819B	550-767FN
O575	GNP191.1P	—	550-819B	550-767EN
R914	GDE131.1P	—	—	540-104N
R916	GMA131.1P	—	—	540-104N
W914	GDE131.1P	—	—	540-200N
W916	GMA131.1P	—	—	540-200N

\*No enclosure included.

## BACnet

Control Package	Includes the following Control Components:			
	Actuator Part Number	Transducer Part Number	Flow Transmitter Part Number	Controller Part Number
ECBE	GNP191.1P	—	550-819B	570-803PA
ECBO	GNP191.1P	—	550-819B	—
GCBF	GMA131.1P	—	550-819B	570-801PA
GCBG	GMA131.1P	—	550-819B	570-805PA
GCBH	GMA131.1P	—	550-819B	570-811PA
GCBN	GMA131.1P	—	550-819B	570-810PA
GCBO	GMA131.1P	—	550-819B	—
GXBF	GDE131.1P	—	550-819B	570-801PA
GXBG	GDE131.1P	—	550-819B	570-805PA
GXBH	GDE131.1P	—	550-819B	570-811PA
GXBN	GDE131.1P	—	550-819B	570-810PA
GXBO	GDE131.1P	—	550-819B	—

## Lab DXR BACnet IP

Control Package	Includes the following Control Components:			
	Actuator Part Number	Transducer Part Number	Flow Transmitter Part Number	Controller Part Number
EC11	GNP191.1P	—	DXA.S04P1	DXR2.E17C-103B
EC12	GNP191.1P	—	DXA.S04P1	DXR2.E17CX-103B
EC10	GMA131.1P	—	DXA.S04P1	—
GC11	GMA131.1P	—	DXA.S04P1	DXR2.E17C-103B
GC12	GMA131.1P	—	DXA.S04P1	DXR2.E17CX-103B
GC10	GMA131.1P	—	DXA.S04P1	—
GX11	GDE131.1P	—	DXA.S04P1	DXR2.E17C-103B
GX12	GDE131.1P	—	DXA.S04P1	DXR2.E17CX-103B
GX10	GDE131.1P	—	DXA.S04P1	—

## Control Components

Part Number	Description	Part Number	Description
540-200N	Variable Volume TEC with Auto-Zero Module	550-819B DXR2.E17C-103B DXR2.E17CX-103B DXA.S04P1 540-104N	BACnet OAM - Off-board Air Module Lab DXR BACnet IP Controller, 30 dp Lab DXR BACnet IP Controller, 60 dp Lab DXR Airflow Pressure Sensor 0-1" Constant Volume TEC with Auto-Zero Module
550-767GN	Lab Controller Module, Applications 2924/2930, Terminals with Low-Speed Actuator Supply and Venturi Exhaust		
550-767EN	Lab Controller Module, Applications 2921/2927, Terminals with High-Speed Actuator	590-780	Differential Pressure Transmitter, 1" WC, 4-20 mA, 0.4% accuracy
550-767FN	Lab Controller Module, Applications 2923/2929, Terminals with Low-Speed Actuator		
550-767HN	Pressurized Room Controller, Application 2931, Terminals with Low-Speed Actuator	GDE131.1P	Fail-in-Last Position, Floating, 44 in-lb electric actuator

Part Number	Description	Part Number	Description
550-767NN	Pressurized Room Controller, Application 2963, Terminals with Low-Speed Actuator	GMA131.1P	Fail-safe Spring Return Floating, 62 in-lb electric actuator
570-801PA	BACnet Lab Controller Module, Applications 6753/6759, Terminals with Low-Speed Actuator	GDE161.1P	Fail-in-Last Position, Modulation, 44 in-lb electric actuator
570-803PA	BACnet Lab Controller Module, Applications 6751/6757, Terminals with High-Speed Actuator	GMA161.1P	Fail-safe Spring Return Modulating 62 in-lb electric actuator
570-805PA	BACnet Lab Controller Module, Applications 6754/6750, Terminals with Low-Speed Actuator Supply and Venturi Exhaust	GNP191.1P	GNP Fast Acting Lab Electronic Actuator
570-811PA	BACnet Pressurized Room Controller, Application 6761, Terminals with Low-Speed Actuator		
570-810PA	Pressurized Room Controller, Application 6773, Terminals with Low-Speed Actuator		

3. Choose a Shaft and Coil orientation, and append the letter to the part number:

**R** = Shaft/Coil Opposite Side

**S** = Shaft/Coil Same Side

4. Choose the Inlet size (the size of the duct) and append the 2-digit number to the part number.

Inlet Size (in inches)	2-digit number	Inlet Size (in inches)	2-digit number
4	04	12	12
6	06	14	14
8	08	16	16
10	10	16" x 24"	18

5. Choose the Reheat Coil orientation, and append the letters to the part number:

Reheat Coil orientation	
(All coils come with access doors)	
OO	No coil.
AB	1 row, Left
AH	1 row, Left HIGH CAPACITY
BB	2 rows, Left.
BH	2 rows, Left HIGH CAPACITY
CB	3 rows, Left.
DB	4 rows, Left
EB	1 row, Right
EH	1 row, Right HIGH CAPACITY
FB	2 rows, Right
FH	2 rows, Right HIGH CAPACITY
GB	3 rows, Right
HB	4 rows, Right

6. Select the Lining, and append that letter to the part number:

Standard Lining Options	
B	Fiber-free foam

**Custom options**

**NOTE:** Custom options require a longer lead time. Please contact your Siemens representative if you want to choose a Custom option.

Custom Lining Options	
F	Foil-faced fiberglass
M	Solid Metal Liner with sound absorbing material between inner and outer layer
A	Solid metal liner ( <b>M</b> ) with Agion Anit-Microbial coating
X	No liner in discharge casing

7. Choose the Construction type:

**O** = Low Leakage

**T** = Low leakage (**O**) plus a transformer (120/24 CL.2) and a Disconnect Switch

8. (Custom Option – requires a longer lead time) This selection is for **custom orders** only, and will not be accepted in SAP. Please see your Siemens representative if you want to choose an Integral Attenuator:


**3** = 36"

**5** = 60"

After completing your selections, you should have an SAP orderable part number that looks similar to the following example:


**SAMPLE Part Number:** LGSO575R14DBBO

Dimensions




S.I. UNITS mm					IMPERIAL UNITS inches				
OUTLET		INLET	LENGTH		OUTLET		INLET	LENGTH	
W	H	D	L	S	W	H	D	L	S
305	203	102	562	168	12	8	4	22 ⅞	6 ⅝
		152	6				20 ⅞		
305	254	203	12		10	8			
356	318	254	14		12 ½	10			
406	381	305	16		15	12			
508	445	356	600	117	20	17 ½	14	23 ⅞	4 ⅝
610	457	406			24	18	16		

- NOTES:**
- 22GA ZINC COATED STEEL CONSTRUCTION. MECHANICALLY SEALED AND GASKETED.
  - INSULATION 3/4"(19) FIBER FREE FOAM WHICH MEETS REQUIREMENTS OF NFPA 90A & UL-181.
  - ULTRA LOW LEAKAGE CONSTRUCTION - ALL CASING SEAMS COVERED WITH DUCT SEALER.
  - ZINC PLATED STEEL DAMPER SHAFT WITH VISIBLE POSITION INDICATOR
  - POLYETHYLENE DAMPER BEARINGS
  - VOLARA DAMPER SEALS
- OPTIONS:**
- CONTROLS FACTORY MOUNTED.
  - 22GA ZINC COATED STEEL CONTROLS ENCLOSURE.
  - 3 FT DISCHARGE ATTENUATOR (INTEGRAL TO LGS CASING)
  - 5 FT DISCHARGE ATTENUATOR (INTEGRAL TO LGS CASING)



ALL METRIC DIMENSIONS ( ) ARE SOFT CONVERTED.  
IMPERIAL DIMENSIONS ARE CONVERTED TO METRIC AND ROUNDED OT THE NEAREST MILLIMETER


Figure 4. Laboratory Room Single Duct Supply Air Terminal without Reheat



S.I. UNITS mm						IMPERIAL UNITS inches					
OUTLET		INLET		LENGTH		OUTLET		INLET		LENGTH	
W	H	B	A	L	S	W	H	B	A	L	S
965	457	603	403	483	178	38	18	23 7/8	15 7/8	19	7

#### NOTES:

- LARGER ENCLOSURE REQUIRED FOR Q575 CONTROL PACKAGE.
- INTERNAL INSULATION 3/4" (119mm) FIBER FREE FOAM WHICH MEETS REQUIREMENTS OF NFPA 90A AND UL181.
- 22GA ZINC COATED STEEL HOUSING. MECHANICALLY SEALED AND GASKETED.
- HAND OF HOT WATER COIL CONNECTIONS IS DETERMINED VIEWED FROM AIR INLET SIDE. RIGHT HAND AS SHOWN. LEFT HAND IS ALSO AVAILABLE.
- HOT WATER COILS HAVE COPPER TUBES AND ALUMINUM FINS WITH O.D. SWEAT CONNECTIONS.
- METHOD OF VENTING HOT WATER COIL IS TO BE PROVIDED BY INSTALLING CONTRACTOR.
- COIL PERFORMANCE IS RATED AND CERTIFIED IN ACCORDANCE WITH THE CURRENT EDITION OF ARI STANDARD 410.
- ULTRA LOW LEAKAGE CONSTRUCTION - ALL CASING SEAMS COVERED WITH DUCT SEALER.
- ZINC PLATED STEEL DAMPER SHAFT WITH VISIBLE POSITION INDICATOR
- POLYETHYLENE DAMPER BEARINGS
- VOLARA DAMPER SEALS




#### OPTIONS:

- 1 ROW WATER COIL
- 2 ROW WATER COIL
- 3 ROW WATER COIL
- 4 ROW WATER COIL
- CONTROLS FACTORY MOUNTED.
- 22GA ZINC COATED STEEL CONTROLS ENCLOSURE.
- 3 FT DISCHARGE ATTENUATOR
- 5 FT DISCHARGE ATTENUATOR

**Figure 5. Laboratory Room Single Duct Supply Air Terminal Size 18 without Reheat**






S.I. UNITS mm					IMPERIAL UNITS inches				
OUTLET		INLET	LENGTH		OUTLET		INLET	LENGTH	
W	H	D	L	S	W	H	D	L	S
305	203	102	562	168	12	8	4	22 ⅞	6 ⅝
		152	511				6	20 ⅞	
305	254	203			12	10	8		
356	318	254			14	12 ½	10		
406	381	305			16	15	12		
508	445	356	600	117	20	17 ½	14	23 ⅜	4 ⅝
610	457	406			24	18	16		

UNIT SIZE	S, IN(mm)
4-12	6 5/8 (168)
14,16	4 5/8 (117)

#### NOTES:


- INTERNAL INSULATION 3/4" (119mm) FIBER FREE FOAM WHICH MEETS REQUIREMENTS OF NFPA 90A AND UL181.-
- 22GA ZINC COATED STEEL HOUSING. MECHANICALLY SEALED AND GASKETED.
- HAND OF HOT WATER COIL CONNECTIONS IS DETERMINED VIEWED FROM AIR INLET SIDE. RIGHT HAND IS SHOWN. LEFT HAND IS ALSO AVAILABLE.
- HOT WATER COILS HAVE COPPER TUBES AND ALUMINUM FINS WITH O.D. SWEAT CONNECTIONS.
- METHOD OF VENTING HOT WATER COIL IS TO BE PROVIDED BY INSTALLING CONTRACTOR.
- COIL PERFORMANCE IS RATED AND CERTIFIED IN ACCORDANCE WITH THE CURRENT EDITION OF ARI STANDARD 410.
- ULTRA LOW LEAKAGE CONSTRUCTION - ALL CASING SEAMS COVERED WITH DUCT SEALER.
- ZINC PLATED STEEL DAMPER SHAFT WITH VISIBLE POSITION INDICATOR
- POLYETHYLENE DAMPER BEARINGS
- VOLARA DAMPER SEALS



#### OPTIONS:

- 1 ROW WATER COIL
- 2 ROW WATER COIL
- 3 ROW WATER COIL
- 4 ROW WATER COIL
- CONTROLS FACTORY MOUNTED.
- 22GA ZINC COATED STEEL CONTROLS ENCLOSURE.
- 3 FT DISCHARGE ATTENUATOR (INTEGRAL TO LGS CASING)
- 5 FT DISCHARGE ATTENUATOR (INTEGRAL TO LGS CASING)


**Figure 6. Laboratory Room Single Duct Supply Air Terminal with Reheat**



S.I. UNITS mm						IMPERIAL UNITS inches					
OUTLET		INLET		LENGTH		OUTLET		INLET		LENGTH	
W	H	B	A	L	S	W	H	B	A	L	S
965	457	603	403	483	178	38	18	23 7/8	15 7/8	19	7

#### NOTES:

- LARGER ENCLOSURE REQUIRED FOR Q575 CONTROL PACKAGE.
- INTERNAL INSULATION 3/4" (119mm) FIBER FREE FOAM WHICH MEETS REQUIREMENTS OF NFPA 90A AND UL181.
- 22GA ZINC COATED STEEL HOUSING. MECHANICALLY SEALED AND GASKETED.
- HAND OF HOT WATER COIL CONNECTIONS IS DETERMINED VIEWED FROM AIR INLET SIDE. RIGHT HAND AS SHOWN. LEFT HAND IS ALSO AVAILABLE.
- HOT WATER COILS HAVE COPPER TUBES AND ALUMINUM FINS WITH O.D. SWEAT CONNECTIONS.
- METHOD OF VENTING HOT WATER COIL IS TO BE PROVIDED BY INSTALLING CONTRACTOR.
- COIL PERFORMANCE IS RATED AND CERTIFIED IN ACCORDANCE WITH THE CURRENT EDITION OF ARI STANDARD 410.
- ULTRA LOW LEAKAGE CONSTRUCTION - ALL CASING SEAMS COVERED WITH DUCT SEALER.
- ZINC PLATED STEEL DAMPER SHAFT WITH VISIBLE POSITION INDICATOR
- POLYETHYLENE DAMPER BEARINGS
- VOLARA DAMPER SEALS



#### OPTIONS:

- 1 ROW WATER COIL
- 2 ROW WATER COIL
- 3 ROW WATER COIL
- 4 ROW WATER COIL
- CONTROLS FACTORY MOUNTED.
- 22GA ZINC COATED STEEL CONTROLS ENCLOSURE.
- 3 FT DISCHARGE ATTENUATOR
- 5 FT DISCHARGE ATTENUATOR

**Figure 7. Laboratory Room Single Duct Supply Air Terminal Size 18 with Reheat**

**Table 1. Airflow Ranges.**

INLET SIZE	MAXIMUM FLOW @ 1.0"dp		MINIMUM FLOW @ 0.02"dp		FLOW SENSOR INLET AREA		Flow Coefficient
	CFM	L/S	CFM	L/S	SQ. FT	M2	
4	340	160	48	23	0.087	0.008	0.976
6	468	221	66	31	0.196	0.018	0.596
8	923	436	126	59	0.349	0.032	0.660
10	1487	702	210	99	0.545	0.051	0.681
12	2141	1010	303	143	0.785	0.073	0.681
14	3045	1437	431	203	1.069	0.099	0.711
16	4074	1923	576	272	1.396	0.130	0.729
18(16x24)	7785	3674	1101	520	2.667	0.248	0.729

**Table 2. Minimum Non-Recoverable Terminal Pressure Drop Across Assembly.**

Terminal Size	Airflow		Without Reheat (inch W.C)	With Hot Water Coils (in. W.C.)			
	CFM	L/s		1 Row	2 Row	3 Row	4 Row
04	75	35	0.01	0.02	0.03	0.03	0.04
	125	59	0.01	0.03	0.05	0.07	0.08
	225	106	0.01	0.05	0.11	0.16	0.21
	280	132	0.01	0.08	0.15	0.22	0.30
06	125	59	0.01	0.03	0.05	0.07	0.08
	250	118	0.01	0.11	0.18	0.24	0.30
	375	177	0.01	0.24	0.36	0.48	0.59
	500	236	0.01	0.40	0.60	0.78	0.97
08	175	83	0.01	0.03	0.05	0.07	0.09
	375	177	0.01	0.08	0.15	0.23	0.30
	775	366	0.01	0.24	0.49	0.74	0.98
	975	460	0.01	0.35	0.72	1.08	1.43
10	250	118	0.01	0.03	0.05	0.07	0.09
	550	260	0.01	0.08	0.16	0.23	0.30
	1150	543	0.01	0.25	0.51	0.76	1.01
	1450	684	0.01	0.36	0.75	1.11	1.48
12	350	165	0.01	0.03	0.05	0.06	0.09
	380	401	0.01	0.09	0.19	0.27	0.36
	1850	873	0.01	0.32	0.66	0.99	1.31
	2350	1109	0.01	0.48	0.98	1.47	1.96
14	500	236	0.01	0.03	0.05	0.07	0.09
	1250	590	0.01	0.09	0.19	0.28	0.36
	2000	944	0.01	0.20	0.40	0.60	0.80
	2750	1298	0.01	0.33	0.68	1.02	1.36
16	600	283	0.01	0.03	0.05	0.07	0.09
	1400	661	0.01	0.08	0.17	0.25	0.33
	3000	1416	0.01	0.28	0.58	0.87	1.16
	3800	1793	0.01	0.42	0.86	1.29	1.72
18	1500	708	0.01	0.05	0.09	0.14	0.18
	3500	1652	0.01	0.17	0.35	0.53	0.70
	5500	2596	0.01	0.36	0.74	1.11	1.48
	7500	3540	0.01	0.61	1.25	1.86	2.48

**Table 3. Hot Water Reheat Coil Capacities.\***

**UNIT SIZE 04, 06**

1-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss  (ft.wg.)
	75	100	200	300	400	500	600	
	Heating Capacity (MBH)							
0.50	4.4	5.0	6.8	7.9	8.6	9.2	9.6	0.13
0.75	4.6	5.4	7.4	8.8	9.7	10.5	11.0	0.28
1.00	4.7	5.6	7.8	9.3	10.4	11.2	11.9	0.49
1.50	4.9	5.8	8.3	9.9	11.2	12.2	13.0	1.06
2.00	5.0	5.9	8.5	10.3	11.6	12.7	13.6	1.86
2.50	5.0	6.0	8.7	10.5	11.9	13.1	14.0	2.87
3.00	5.0	6.0	8.8	10.7	12.1	13.3	14.3	4.08
4.00	5.1	6.1	8.9	10.9	12.4	13.7	14.7	7.13

**UNIT SIZE 04, 06**

2-Row Coil								
GPM	Airflow, CFM							Waterside Head
	75	100	200	300	400	500	600	Loss
	Heating Capacity (MBH)							(ft.wg.)
0.60	6.3	7.4	10.5	12.3	13.5	14.4	15.1	0.05
0.75	6.5	7.8	11.2	13.3	14.8	15.9	16.8	0.07
1.00	6.7	8.1	12.0	14.5	16.3	17.7	18.8	0.12
1.50	7.0	8.5	13.0	16.0	18.2	20.0	21.4	0.27
2.00	7.2	8.8	13.6	16.9	19.4	21.4	23.0	0.47
2.50	7.3	8.9	13.9	17.5	20.2	22.4	24.2	0.72
3.00	7.3	9.0	14.2	17.9	20.7	23.1	25.0	1.02
4.00	7.4	9.1	14.5	18.4	21.5	24.0	26.1	1.79

**Air Side Pressure Drop (Inches WC)**

0.01	0.01	0.04	0.07	0.12	0.18	0.24
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.02	0.03	0.08	0.16	0.26	0.38	0.51
------	------	------	------	------	------	------

**UNIT SIZE 04, 06**

3- Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	75	100	200	300	400	500	600	
	Heating Capacity (MBH)							
1.00	8.2	10.2	15.7	19.2	21.7	23.6	25.0	0.19
1.50	8.5	10.5	16.8	21.1	24.3	26.8	28.8	0.42
2.00	8.6	10.7	17.5	22.3	25.9	28.8	31.1	0.72
2.50	8.6	10.9	17.9	23.0	26.9	30.1	32.7	1.11
3.00	8.7	11.0	18.2	23.5	27.6	31.0	33.9	1.58
4.00	8.7	11.1	18.5	24.1	28.6	32.3	35.4	2.74
5.00	8.8	11.1	18.8	24.6	29.2	33.1	36.4	4.23
6.00	8.8	11.2	18.9	24.9	29.7	33.7	37.1	6.01

**UNIT SIZE 04, 06**

4- Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	75	100	200	300	400	500	600	
	Heating Capacity (MBH)							
1.5	9.1	11.5	18.9	23.9	27.5	30.3	32.6	0.23
3	9.3	11.9	20.5	26.8	31.8	35.9	39.3	0.88
4	9.4	12.1	20.9	27.7	33.1	37.6	41.4	1.55
5	9.4	12.1	21.2	28.2	34.0	38.7	42.8	2.39
6	9.4	12.2	21.4	28.6	34.5	39.5	43.8	3.41
7	9.5	12.2	21.5	28.9	34.9	40.1	44.5	4.61
8	9.5	12.2	21.6	29.1	35.3	40.5	45.1	5.98
9	9.5	12.2	21.7	29.2	35.5	40.9	45.6	7.53

**Air Side Pressure Drop (Inches WC)**

0.02	0.04	0.12	0.24	0.39	0.56	0.77
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.03	0.05	0.16	0.32	0.52	0.75	1.02
------	------	------	------	------	------	------

**UNIT SIZE 08**

1-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	150	350	500	650	800	950	1100	
	Heating Capacity (MBH)							
0.5	6.9	9.6	10.7	11.5	12.1	12.6	13.0	0.17
1.0	7.8	11.4	13.1	14.4	15.3	16.1	16.8	0.66
1.5	8.1	12.3	14.2	15.7	16.9	17.9	18.7	1.44
2.0	8.3	12.7	14.8	16.5	17.8	18.9	19.8	2.50
2.5	8.4	13.0	15.2	17.0	18.4	19.6	20.6	3.85
3.0	8.5	13.2	15.5	17.3	18.8	20.1	21.2	5.48
4.0	8.6	13.5	15.9	17.8	19.4	20.7	21.9	9.56
4.5	8.7	13.6	16.1	18.0	19.6	21.0	22.2	12.01

**UNIT SIZE 08**

2-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	150	350	500	650	800	950	1100	
	Heating Capacity (MBH)							
0.6	10.2	14.7	16.4	17.7	18.5	19.2	19.8	0.06
1.0	11.4	17.5	20.2	22.1	23.6	24.7	25.7	0.17
2.0	12.5	20.5	24.4	27.3	29.7	31.6	33.2	0.64
3.0	12.9	21.8	26.2	29.7	32.5	34.9	36.9	1.39
4.0	13.2	22.5	27.3	31.1	34.2	36.8	39.1	2.43
5.0	13.3	23.0	28.0	32.0	35.3	38.1	40.5	3.72
6.0	13.4	23.3	28.5	32.6	36.1	39.0	41.6	5.32
7.0	13.5	23.5	28.8	33.1	36.7	39.7	42.4	7.14

**Air Side Pressure Drop (Inches WC)**

0.01	0.06	0.11	0.17	0.24	0.33	0.42
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.03	0.13	0.23	0.36	0.51	0.68	0.87
------	------	------	------	------	------	------

**\* Notes:**

All capacities are based on 180°F entering water temperature and 55°F entering air temperature. For other air and water inlet temperature conditions, use the correction factors shown in Table 4 to multiply the given heating capacity for each size.  
 1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise

**Table 3. Hot Water Reheat Coil Capacities.\***

UNIT SIZE 08								
3-Row Coil								Waterside Head Loss (ft.wg.)
GPM	Airflow, CFM							
	150	350	500	650	800	950	1100	
	Heating Capacity (MBH)							
1.0	14.4	23.0	26.6	29.1	30.9	32.4	33.5	0.26
1.5	15.1	25.5	30.2	33.7	36.4	38.5	40.3	0.57
2.0	15.5	26.9	32.4	36.5	39.8	42.5	44.7	0.98
2.5	15.8	27.8	33.8	38.5	42.2	45.2	47.8	1.51
3.0	15.9	28.4	34.8	39.8	43.9	47.2	50.1	2.14
4.0	16.1	29.3	36.2	41.7	46.2	50.0	53.3	3.71
5.0	16.2	29.8	37.1	42.9	47.7	51.8	54.4	5.71
6.0	16.3	30.2	37.7	43.7	48.8	53.1	56.9	8.11

Air Side Pressure Drop (Inches WC)							
0.05	0.19	0.35	0.54	0.77	1.02	1.31	

UNIT SIZE 08								
4-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	150	350	500	650	800	950	1100	
	Heating Capacity (MBH)							
2.0	16.8	29.6	35.6	40.0	43.4	46.1	48.3	0.27
2.5	17.1	30.8	37.6	42.6	46.6	49.9	52.5	0.42
3.0	17.3	31.7	39.0	44.6	49.0	52.7	55.7	0.59
4.0	17.6	32.9	40.9	47.3	52.4	56.7	60.3	1.04
6.0	17.8	34.1	43.0	50.3	56.3	61.4	65.8	2.30
8.0	17.9	34.7	44.2	51.9	58.4	64.0	68.9	4.04
10.0	18.0	35.2	44.9	53.0	59.8	65.7	70.9	6.26
12.0	18.1	35.4	45.4	53.7	60.8	66.9	72.3	8.95

Air Side Pressure Drop (Inches WC)							
0.06	0.26	0.46	0.72	1.02	1.36	1.74	

UNIT SIZE 10								
1-Row Coil								Waterside Head Loss (ft.wg.)
GPM	Airflow, CFM							
	200	400	600	800	1000	1400	1600	
	Heating Capacity (MBH)							
1.0	9.9	13.4	15.5	17.0	18.1	19.7	20.3	0.11
2.0	11.0	15.4	18.3	20.5	22.1	24.6	25.6	0.42
3.0	11.4	16.3	19.6	22.0	23.9	26.9	28.1	0.92
4.0	11.6	16.8	20.3	22.9	25.0	28.3	29.6	1.60
5.0	11.8	17.1	20.7	23.5	25.7	29.2	30.6	2.47
6.0	11.9	17.3	21.0	23.9	26.2	29.9	31.3	3.52
7.0	11.9	17.5	21.3	24.2	26.6	30.4	31.9	4.74
8.0	12.0	17.6	21.4	24.4	26.9	30.7	32.3	6.13

Air Side Pressure Drop (Inches WC)							
0.01	0.04	0.08	0.13	0.19	0.33	0.42	

UNIT SIZE 10								
2-Row Coil								Waterside Head Loss (ft.wg.)
GPM	Airflow, CFM							
	200	400	600	800	1000	1400	1600	
	Heating Capacity (MBH)							
1.0	14.5	20.4	23.8	26.1	27.7	30.0	30.9	0.23
2.0	16.4	24.5	29.8	33.6	36.5	40.8	42.5	0.88
3.0	17.2	26.3	32.5	37.2	40.9	46.4	48.6	1.93
4.0	17.6	27.3	34.2	39.4	43.5	49.9	52.5	3.35
5.0	17.9	28.0	35.2	40.8	45.3	52.3	55.1	5.14
6.0	18.0	28.5	36.0	41.8	46.6	54.0	57.1	7.31
7.0	18.2	28.8	36.5	42.6	47.6	55.4	58.6	9.84
8.0	18.3	29.1	37.0	43.2	48.3	56.4	59.7	12.73

Air Side Pressure Drop (Inches WC)							
0.03	0.09	0.17	0.27	0.39	0.69	0.87	

UNIT SIZE 10								
3-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	200	400	600	800	1000	1400	1600	
	Heating Capacity (MBH)							
1.5	19.8	29.9	36.1	40.3	43.4	47.8	49.3	0.29
3.0	21.2	34.0	42.9	49.5	54.7	62.5	65.5	1.12
4.0	21.6	35.2	45.0	52.5	58.4	67.6	71.2	1.97
5.0	21.8	35.9	46.3	54.3	60.9	71.0	75.0	3.03
6.0	21.9	36.5	47.2	55.7	62.6	73.5	77.9	4.32
7.0	22.0	36.8	47.9	56.7	63.9	75.4	80.0	5.84
8.0	22.1	37.1	48.4	57.5	64.9	76.8	81.7	7.57
9.0	22.2	37.3	48.8	58.1	65.8	78.0	83.1	9.51

Air Side Pressure Drop (Inches WC)							
0.04	0.13	0.25	0.41	0.59	1.04	1.30	

UNIT SIZE 10								
4-Row Coil								Waterside Head Loss (ft.wg.)
GPM	Airflow, CFM							
	200	400	600	800	1000	1400	1600	
	Heating Capacity (MBH)							
2.0	22.5	36.0	44.7	50.7	55.2	61.5	63.8	0.33
2.5	23.0	37.5	47.3	54.4	59.8	67.5	70.4	0.51
3.0	23.3	38.6	49.2	57.1	63.2	72.2	75.6	0.73
4.0	23.6	39.9	51.8	60.8	68.0	78.9	83.2	1.28
6.0	24.0	41.3	54.5	65.0	73.5	86.9	92.2	2.82
8.0	24.2	42.1	56.0	67.2	76.6	91.4	97.5	4.94
10.0	24.3	42.5	56.9	68.6	78.5	94.4	100.9	7.65
12.0	24.3	42.8	57.5	69.6	79.9	96.4	103.3	10.92

Air Side Pressure Drop (Inches WC)							
0.06	0.17	0.34	0.54	0.79	1.39	1.74	

**\* Notes:**

All capacities are based on 180°F entering water temperature and 55°F entering air temperature. For other air and water inlet temperature conditions, use the correction factors shown in Table 4 to multiply the given heating capacity for each size.  
1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise

**Table 3. Hot Water Reheat Coil Capacities.\***

UNIT SIZE 12								
1-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	400	600	800	1200	1600	2000	2500	
	Heating Capacity (MBH)							
2.0	17.9	21.5	24.1	27.9	30.7	32.8	34.8	0.55
3.0	18.8	22.9	25.9	30.5	33.8	36.3	38.9	1.21
4.0	19.4	23.7	27.0	31.9	35.6	38.5	41.4	2.11
5.0	19.7	24.2	27.7	32.9	36.8	39.9	43.0	3.24
6.0	20.0	24.6	28.1	33.6	37.6	40.9	44.2	4.61
7.0	20.1	24.8	28.5	34.1	38.3	41.7	45.1	6.22
9.0	20.4	25.2	29.0	34.8	39.2	42.8	46.4	10.11
10.0	20.4	25.3	29.1	35.0	39.4	43.0	46.7	11.22

Air Side Pressure Drop (Inches WC)							
0.02	0.04	0.07	0.15	0.24	0.36	0.52	

UNIT SIZE 12								
2-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	400	600	800	1200	1600	2000	2500	
	Heating Capacity (MBH)							
2.0	28.1	34.8	39.8	46.9	51.9	55.5	59.1	0.45
3.0	29.9	37.7	43.8	52.7	59.1	64.0	68.8	0.99
4.0	30.9	39.4	46.0	56.1	63.4	69.2	75.0	1.74
5.0	31.5	40.5	47.5	58.3	66.4	72.8	79.2	2.68
6.0	32.0	41.2	48.6	59.9	68.5	75.4	82.3	3.83
7.0	32.3	41.8	49.4	61.1	70.1	77.3	84.7	5.17
9.0	32.8	42.5	50.4	62.9	72.4	80.1	88.1	8.45
10.0	32.9	42.8	50.8	63.5	73.2	81.2	89.3	10.37

Air Side Pressure Drop (Inches WC)							
0.05	0.10	0.16	0.32	0.51	0.74	1.08	

UNIT SIZE 12								
3-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	400	600	800	1200	1600	2000	2500	
	Heating Capacity (MBH)							
1.5	33.1	40.4	45.5	52.0	56.1	58.9	61.5	0.37
3.0	37.3	47.9	55.9	67.3	75.3	81.2	86.9	1.40
4.0	38.5	50.0	59.0	72.4	82.0	89.3	96.5	2.44
5.0	39.2	51.4	61.1	75.7	86.5	94.9	103.2	3.76
6.0	39.7	52.3	62.5	78.1	89.8	99.0	108.1	5.34
7.0	40.0	53.0	63.5	79.9	92.2	102.1	111.9	7.22
9.0	40.5	54.0	65.0	82.4	95.7	106.5	117.4	11.73
10.0	40.7	54.3	65.5	83.3	97.0	108.1	119.5	14.42

Air Side Pressure Drop (Inches WC)							
0.08	0.15	0.24	0.47	0.77	1.11	1.62	

UNIT SIZE 12								
4-Row Coil								
GPM	Airflow, CFM							Waterside Head
	400	600	800	1200	1600	2000	2500	Loss
	Heating Capacity (MBH)							(ft.wg.)
2.0	39.3	49.5	56.7	66.3	72.3	76.5	80.3	0.40
4.0	43.0	56.9	67.7	83.7	95.0	103.5	111.6	1.55
5.0	43.8	58.5	70.2	88.0	101.0	110.9	120.6	2.40
6.0	44.3	59.6	72.0	91.1	105.3	116.4	127.3	3.42
8.0	45.0	61.0	74.3	95.2	111.2	123.9	136.7	5.96
9.0	45.2	61.5	75.1	96.6	113.2	126.6	140.1	7.51
10.0	45.4	61.9	75.7	97.8	114.9	128.8	142.9	9.22
12.0	45.6	62.5	76.7	99.6	117.6	132.3	147.3	13.16

Air Side Pressure Drop (Inches WC)							
0.10	0.20	0.32	0.63	1.02	1.49	2.16	

UNIT SIZE 14								
1-Row Coil								Waterside Head Loss (ft.wg.)
GPM	Airflow, CFM							
	500	800	1200	1700	2200	2700	3400	
	Heating Capacity (MBH)							
1.0	20.0	23.8	26.9	29.5	31.2	32.5	33.9	0.20
2.0	23.4	28.9	33.8	38.1	41.2	43.6	46.3	0.76
3.0	24.8	31.1	36.9	42.2	46.1	49.2	52.7	1.65
4.0	25.6	32.4	38.8	44.6	49.0	52.6	56.6	2.87
5.0	26.1	33.2	40.0	46.2	51.0	54.8	59.2	4.41
6.0	26.4	33.7	40.8	47.3	52.4	56.5	61.2	6.26
8.0	26.9	34.5	41.9	48.9	54.3	58.7	63.8	10.92
10.0	27.2	35.0	42.6	49.8	55.5	60.1	65.5	16.80

Air Side Pressure Drop (Inches WC)							
0.02	0.04	0.08	0.14	0.22	0.31	0.46	

UNIT SIZE 14								
2-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	500	800	1200	1700	2200	2700	3400	
	Heating Capacity (MBH)							
1.5	32.3	40.0	46.4	51.5	55.0	57.5	60.1	0.33
3.0	37.6	48.8	59.1	68.1	74.7	79.8	85.2	1.27
4.0	39.1	51.6	63.4	74.0	81.9	88.2	95.0	2.21
5.0	40.2	53.4	66.3	78.0	87.0	94.1	102.0	3.41
6.0	40.9	54.7	68.3	81.0	90.7	98.5	107.2	4.85
7.0	41.4	55.7	69.9	83.2	93.5	101.8	111.3	6.55
9.0	42.1	57.0	72.1	86.4	97.6	106.8	117.3	10.65
10.0	42.4	57.5	72.9	87.6	99.1	108.6	119.5	13.09

Air Side Pressure Drop (Inches WC)							
0.04	0.09	0.17	0.30	0.46	0.65	0.96	

**\* Notes:**

All capacities are based on 180°F entering water temperature and 55°F entering air temperature. For other air and water inlet temperature conditions, use the correction factors shown in Table 4 to multiply the given heating capacity for each size.  
 1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise

**Table 3. Hot Water Reheat Coil Capacities.\***

**UNIT SIZE 14**

3-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	500	800	1200	1700	2200	2700	3400	
	Heating Capacity (MBH)							
2	43.7	55.5	65.3	72.9	77.9	81.5	85.0	0.41
4	48.8	65.7	81.5	95.3	105.3	113.0	121.1	1.55
5	49.9	68.0	85.5	101.2	112.9	121.9	131.8	2.40
6	50.6	69.6	88.3	105.5	118.4	128.7	140.0	3.42
8	51.6	71.6	92.0	111.2	126.1	138.0	151.4	5.97
9	51.9	72.4	93.3	113.3	128.8	141.4	155.6	7.52
10	52.1	72.9	94.4	115.0	131.1	144.2	159.1	9.23
12	52.5	73.8	96.0	117.6	134.6	148.6	164.7	13.15

**UNIT SIZE 14**

4-Row Coil								
GPM	Airflow, CFM							Waterside Head
	500	800	1200	1700	2200	2700	3400	Loss
	Heating Capacity (MBH)							(ft.wg.)
3.5	52.6	70.8	87.1	100.7	110.0	116.8	123.8	0.49
7	56.3	79.2	102.3	123.5	139.5	152.0	165.8	1.90
10	57.4	82.0	107.6	132.1	151.1	166.5	183.7	3.83
12	57.8	83.1	109.8	135.7	156.1	172.7	191.7	5.49
14	58.1	83.9	111.3	138.3	159.8	177.5	197.7	7.43
16	58.4	84.5	112.6	140.4	162.7	181.2	202.5	9.67
19	58.6	85.2	113.9	142.7	166.0	185.5	208.1	13.57
21	58.8	85.5	114.6	143.9	167.7	187.7	211.0	16.53

**Air Side Pressure Drop (Inches WC)**

0.06	0.13	0.25	0.45	0.69	0.98	1.44
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.08	0.17	0.34	0.60	0.93	1.31	1.92
------	------	------	------	------	------	------

**UNIT SIZE 16**

1-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	600	1000	1500	2000	2500	3500	4400	
	Heating Capacity (MBH)							
2.0	27.5	34.3	39.9	43.8	46.8	51.2	54.0	0.86
3.0	29.3	37.3	44.0	49.0	52.8	58.6	62.4	1.87
4.0	30.4	39.0	46.5	52.1	56.4	63.1	67.6	3.25
5.0	31.0	40.1	48.1	54.1	58.9	66.2	71.2	5.00
6.0	31.5	40.9	49.3	55.6	60.6	68.4	73.8	7.08
7.0	31.8	41.5	50.1	56.7	62.0	70.2	75.8	9.55
8.0	32.1	41.9	50.8	57.5	63.0	71.5	77.4	12.35
10.0	32.5	42.6	51.8	58.8	64.5	73.5	79.8	19.00

**UNIT SIZE 16**

2-Row Coil								
GPM	Airflow, CFM							Waterside Head
	600	1000	1500	2000	2500	3500	4400	Loss
	Heating Capacity (MBH)							(ft.wg.)
2.0	40.4	51.5	60.2	66.0	70.3	76.1	79.7	0.64
3.0	44.1	57.9	69.5	77.7	83.9	92.8	98.4	1.40
4.0	46.2	61.8	75.3	85.1	92.7	103.9	111.3	2.45
5.0	47.5	64.3	79.2	90.2	98.9	111.9	120.6	3.77
6.0	48.5	66.1	82.0	94.0	103.5	117.9	127.6	5.35
7.0	49.2	67.5	84.1	96.8	107.0	122.6	133.2	7.24
9.0	50.2	69.4	87.2	100.9	112.1	129.4	141.4	11.75
10.0	50.5	70.1	88.3	102.5	114.0	132.0	144.5	14.44

**Air Side Pressure Drop (Inches WC)**

0.02	0.04	0.08	0.14	0.20	0.36	0.53
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.04	0.09	0.18	0.29	0.42	0.74	1.09
------	------	------	------	------	------	------

**UNIT SIZE 16**

3-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	600	1000	1500	2000	2500	3500	4400	
	Heating Capacity (MBH)							
2.5	52.7	68.5	80.5	88.3	93.7	101.0	105.4	0.42
5.0	58.7	81.0	100.4	114.4	125.0	140.4	150.2	1.62
6.0	59.8	83.4	104.5	120.0	132.0	149.7	161.2	2.31
8.0	61.1	86.5	109.9	127.7	141.7	163.0	177.2	4.06
10.0	61.9	88.5	113.4	132.7	148.2	172.0	188.2	6.26
12.0	62.5	89.8	115.9	136.2	152.8	178.5	196.2	8.96
13.0	62.7	90.4	116.8	137.6	154.6	181.1	199.5	10.47
15.0	63.1	91.2	118.4	139.9	157.6	185.5	204.9	13.84

**UNIT SIZE 16**

4-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	600	1000	1500	2000	2500	3500	4400	
	Heating Capacity (MBH)							
4.5	63.5	87.8	108.0	121.9	132.2	146.3	155.0	0.59
9.0	67.7	98.2	126.5	148.0	165.0	190.4	207.1	2.33
12.0	68.8	101.0	131.9	156.0	175.5	205.3	225.5	4.12
15.0	69.4	102.7	135.3	161.1	182.3	215.3	238.1	6.40
18.0	69.8	103.9	137.7	164.7	187.1	222.5	247.2	9.19
22.0	70.2	105.0	139.9	168.1	191.7	229.4	256.0	13.68
25.0	70.5	105.6	141.1	170.0	194.3	233.4	261.1	17.62
27.0	70.6	106.0	141.7	171.0	195.7	235.5	263.9	20.53

**Air Side Pressure Drop (Inches WC)**

0.06	0.14	0.27	0.44	0.63	1.11	1.64
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

.08	0.18	0.36	0.58	0.84	1.49	2.18
-----	------	------	------	------	------	------

**\* Notes:**

All capacities are based on 180°F entering water temperature and 55°F entering air temperature. For other air and water inlet temperature conditions, use the correction factors shown in Table 4 to multiply the given heating capacity for each size.

1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise

**Table 3. Hot Water Reheat Coil Capacities.\***

UNIT SIZE 18								
1-Row Coil								
GPM	Airflow, CFM							Waterside
	1500	2000	3000	4000	5000	6000	8000	Head
								Loss
Heating Capacity (MBH)								(ft.wg.)
2.0	48.6	53.7	60.6	65.2	68.7	71.3	75.2	1.22
3.0	54.1	60.6	69.9	76.3	81.2	85.1	91.0	2.66
4.0	57.4	64.8	75.6	83.3	89.2	94.0	101.3	4.60
5.0	59.5	67.6	79.4	88.0	94.7	100.2	108.7	7.07
6.0	61.0	69.5	82.2	91.5	98.8	104.8	114.2	10.00
7.0	62.2	71.0	84.3	94.1	101.9	108.3	118.4	13.48
8.0	63.0	72.2	85.9	96.2	104.4	111.1	121.8	17.42
10.0	64.3	73.9	88.4	99.3	108.0	115.3	126.9	26.76

UNIT SIZE 18								
2-Row Coil								
GPM	Airflow, CFM							Waterside Head
	1500	2000	3000	4000	5000	6000	8000	Loss
	Heating Capacity (MBH)							(ft.wg.)
2.0	69.3	76.3	85.2	90.7	94.4	97.1	100.8	0.87
3.0	80.8	91.0	104.8	113.8	120.2	125.1	132.1	1.89
4.0	87.9	100.3	117.8	129.7	138.5	145.3	155.2	3.30
5.0	92.6	106.7	127.0	141.3	152.0	160.4	173.0	5.07
6.0	96.1	111.4	134.0	150.1	162.4	172.2	187.0	7.19
7.0	98.7	115.0	139.4	157.0	170.6	181.6	198.4	9.68
8.0	100.8	117.9	143.6	162.5	177.3	189.2	207.7	12.52
10.0	103.8	122.1	150.1	171.0	187.5	201.0	222.2	19.25

**Air Side Pressure Drop (Inches WC)**

0.04	0.06	0.12	0.20	0.30	0.41	0.67
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.08	0.13	0.27	0.43	0.63	0.85	1.38
------	------	------	------	------	------	------

UNIT SIZE 18								
3-Row Coil								
GPM	Airflow, CFM							Waterside Head Loss (ft.wg.)
	1500	2000	3000	4000	5000	6000	8000	
	Heating Capacity (MBH)							
2.5	93.3	102.6	113.7	120.2	124.4	127.3	131.3	0.54
4	110.3	125.4	145.3	157.9	166.7	173.1	182.2	1.34
5	116.8	134.7	159.1	175.2	186.7	195.5	207.9	2.05
6	121.4	141.4	169.5	188.5	202.5	213.3	228.9	2.93
8	127.5	150.4	183.9	207.7	225.6	239.7	260.8	5.12
10	131.3	156.1	193.4	220.6	241.6	258.3	283.9	7.88
12	133.9	160.1	200.2	230.0	253.2	272.1	301.2	11.25
15	136.5	164.2	207.3	239.9	265.8	287.1	320.5	17.33

4-Row Coil								
GPM	Airflow, CFM							Waterside Head
	1500	2000	3000	4000	5000	6000	8000	Loss
	Heating Capacity (MBH)							(ft.wg.)
4.5	125.0	142.8	165.9	180.1	189.8	196.9	206.6	0.67
9	144.8	172.5	213.1	241.5	262.7	279.2	303.5	2.64
12	150.2	181.1	228.0	262.2	288.6	309.5	341.2	4.65
15	153.4	186.4	237.6	276.0	306.1	330.5	368.0	7.22
18	155.7	190.1	244.4	285.8	318.7	345.8	387.9	10.35
21	157.3	192.7	249.4	293.1	328.3	357.4	403.3	14.03
24	158.5	194.7	253.2	298.8	335.7	366.5	415.5	18.27
27	159.4	196.3	256.2	303.3	341.7	373.9	425.5	23.05

**Air Side Pressure Drop (Inches WC)**

0.13	0.20	0.40	0.64	0.94	1.27	2.07
------	------	------	------	------	------	------

**Air Side Pressure Drop (Inches WC)**

0.17	0.27	0.53	0.86	1.25	1.70	2.76
------	------	------	------	------	------	------

**\* Notes:**

All capacities are based on 180°F entering water temperature and 55°F entering air temperature. For other air and water inlet temperature conditions, use the correction factors shown in Table 4 to multiply the given heating capacity for each size.

1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise

**Table 4. Capacity Correction Data for 1,2,3 and 4 Hot Water Reheat Coils.**

Entering Air Temp. (°F)	Entering Water Temperature (°F)												Entering Air Temp. (°F)
	120	130	140	150	160	170	180	190	200	210	220		
50	0.54	0.62	0.71	0.79	0.87	0.96	1.04	1.12	1.21	1.29	1.38		50
55	0.50	0.59	0.67	0.75	0.83	0.92	1.0	1.08	1.17	1.25	1.34		55
60	0.47	0.55	0.63	0.71	0.79	0.88	0.96	1.04	1.13	1.21	1.30		60
65	0.43	0.51	0.59	0.67	0.75	0.84	0.92	1.00	1.09	1.17	1.26		65

**Note:**

1 MBH = 1000 BTU/Hr. MBH Required = 0.00108 × CFM × Temp. Rise



**Table 5. Single Duct Supply Air Terminal Casing & Damper Leakage (in CFM).**

Unit Size	Casing Leakage			Damper Leakage		
	1.0" WC	3.0" WC	6.0" WC	1.5" WC	3.0" WC	6.0" WC
4	1	2	3	4	5	6
6	1	2	3	4	6	11
8	1	2	3	5	7	10
10	1	2	3	6	7	10
12	1	2	4	8	12	19
14	2	3	5	6	10	16
16	2	4	7	13	21	38
18	3	6	12	98	154	305

**Performance Notes on Leakage Data:**

1. Tests conducted in accordance with AHRI 880-2011 and ASHRAE Standard 130-1996, "Methods of Testing for Rating Ducted Air Terminal Units".
2. All pressures in the tables above are based on inlet static pressure in inches of water gauge, in. W.G.
3. Airflows are given in cubic feet per minute (CFM).
4. All data is based on E.H. Price Limited Laboratory Test Files F3700 (casing leakage) and F398 (damper leakage).
5. Optional Reheat Leakage information is not included in the table.

**Table 6. Discharge Sound Data for Single Duct Supply Air Terminal.**

(Sound Power Levels, Lw dB, re 10<sup>-12</sup> Watts)

			125 Pa (0.5" W.G.)							250 Pa (1.0" W.G.)							500 Pa (2.0" W.G.)							750 Pa (3.0" W.G.)						
Unit Size	Airflow		Octave Band							Octave Band							Octave Band							Octave Band						
	cfm	L/s	2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7	
4	75	35	45	45	43	39	34	32		46	47	47	44	41	39		48	49	51	48	47	46		49	50	54	51	51	50	
	150	71	56	57	51	47	41	36		58	59	55	52	47	43		59	61	59	57	53	50		60	62	62	59	57	55	
	225	106	63	63	56	52	44	39		64	65	60	57	51	46		66	67	64	61	57	53		67	68	67	64	60	57	
	280	132	66	67	58	55	46	40		68	69	63	59	52	47		69	71	67	64	59	55		70	72	69	67	62	59	
6	125	59	46	45	44	39	35	34		49	49	49	44	42	41		52	53	54	49	49	48		54	56	57	52	53	52	
	250	118	55	54	51	47	40	38		58	58	56	52	47	45		61	62	61	57	53	52		63	65	64	60	57	56	
	375	177	60	59	55	51	43	40		63	63	60	56	49	47		66	68	65	61	56	54		68	70	69	64	60	58	
	500	236	63	63	58	54	44	42		67	67	63	59	51	49		70	71	68	64	58	56		72	74	72	67	62	60	
	630	297	66	66	60	57	46	43		69	70	66	62	53	50		73	74	71	67	59	57		74	77	74	70	63	61	
8	175	83	47	43	43	38	35	33		51	50	49	44	42	40		56	56	56	49	49	47		59	60	59	53	53	52	
	375	177	54	51	49	46	40	37		59	57	55	51	47	45		63	64	62	57	54	52		66	67	66	61	58	56	
	575	271	58	55	52	50	43	40		63	62	59	56	50	47		67	68	65	62	57	55		70	72	69	65	61	59	
	775	366	61	58	55	53	46	42		65	65	61	59	52	49		70	71	68	65	59	56		73	75	72	68	63	61	
	975	460	63	61	57	56	47	43		68	67	63	61	54	51		72	73	70	67	61	58		75	77	73	71	65	62	
	1115	526	64	62	58	57	48	44		69	68	64	63	55	51		74	75	71	69	62	59		76	79	75	72	66	63	
10	250	118	51	47	48	44	40	37		55	55	55	50	47	45		60	63	62	56	54	52		63	68	66	60	58	56	
	550	260	56	52	53	50	44	41		61	60	60	56	51	48		66	68	66	62	58	56		69	72	70	65	62	60	
	850	401	59	55	55	52	46	43		64	63	62	59	53	50		69	71	69	65	60	58		72	75	73	68	64	62	
	1150	543	61	57	57	55	48	45		66	65	64	61	55	52		71	72	70	67	62	59		74	77	74	70	66	63	
	1450	684	63	58	58	56	49	46		68	66	65	62	56	53		73	74	72	68	63	60		75	78	76	72	67	64	
	1745	824	64	59	59	57	50	47		69	67	66	64	57	54		74	75	73	70	64	61		77	80	77	73	68	65	
12	350	165	49	49	49	46	41	39		54	56	56	52	47	46		60	63	63	59	54	53		63	67	67	62	58	57	
	850	401	56	54	53	51	45	43		61	61	60	57	52	50		66	68	67	63	59	57		69	73	71	67	63	61	
	1350	637	59	57	56	53	48	45		65	64	63	59	55	52		70	71	70	66	62	59		73	75	74	69	66	63	
	1850	873	62	59	58	55	49	46		67	66	65	61	56	53		72	73	72	67	63	61		75	77	76	71	67	65	
	2350	1109	64	60	59	56	50	47		69	67	66	62	57	54		74	74	73	68	64	62		77	79	77	72	68	66	
	2515	1187	64	61	59	56	51	48		69	68	66	63	58	55		75	75	73	69	65	62		78	79	77	73	69	66	
14	500	236	51	49	48	46	41	38		58	57	55	53	48	46		65	64	62	59	54	53		69	68	65	63	59	58	
	1250	590	56	54	54	52	46	43		63	61	61	58	53	51		70	68	67	65	60	58		73	72	71	69	64	62	
	2000	944	59	56	57	55	49	46		65	63	64	61	56	53		72	70	70	68	63	61		76	74	74	71	67	65	
	2750	1298	60	57	59	57	51	47		67	64	66	63	58	55		74	72	73	70	65	62		78	76	76	73	69	67	
	3420	1614	61	58	61	58	53	48		68	65	67	65	60	56		75	73	74	71	67	63		79	77	78	75	71	68	

**Table 6. Discharge Sound Data for Single Duct Supply Air Terminal.**(Sound Power Levels, Lw dB, re 10<sup>-12</sup> Watts)

			125 Pa (0.5" W.G.)							250 Pa (1.0" W.G.)							500 Pa (2.0" W.G.)							750 Pa (3.0" W.G.)						
Unit Size	Airflow		Octave Band							Octave Band							Octave Band							Octave Band						
	cfm	L/s	2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7	
16	600	283	49	46	46	46	43	42		55	53	52	52	49	49		61	60	59	58	55	56		65	64	62	62	59	60	
	1400	661	55	51	52	51	48	46		62	58	58	57	54	53		68	65	65	63	60	59		71	70	69	67	64	63	
	2200	1038	59	54	55	54	50	48		65	61	62	60	56	54		71	68	68	66	63	61		75	72	72	70	66	65	
	3000	1416	61	56	57	56	52	49		67	63	64	62	58	56		74	70	70	68	64	62		77	74	74	71	68	66	
	3800	1793	63	58	59	58	53	50		69	65	65	63	59	57		75	72	72	69	66	63		79	76	76	73	69	67	
	4470	2110	64	59	60	58	54	51		71	66	67	64	60	57		77	73	73	70	66	64		80	77	77	74	70	68	
18	1500	708	55	53	51	51	48	45		60	58	57	57	53	50		65	64	63	63	58	55		68	67	66	66	60	59	
	3500	1652	65	62	61	60	57	53		70	68	67	66	62	59		75	73	73	71	67	64		78	76	76	75	70	67	
	5500	2596	70	67	66	64	63	58		75	73	72	70	67	63		80	78	78	76	72	69		83	82	81	79	75	72	
	7500	3540	74	71	70	68	66	61		79	76	76	73	71	67		84	82	81	79	76	72		87	85	85	82	79	75	
	8530	4026	75	72	71	69	67	63		80	78	77	75	72	68		85	83	83	80	77	73		88	86	86	84	80	76	

**Performance Notes:**

1. Tested in accordance with AHRI 880-2011 and ASHRAE Standard 130-1996: "Methods of Testing for Rating Ducted Air Terminal Units".
2. Airflow given in liters/second L/s; and cubic feet/minute, cfm.
3. Blank spaces "-" indicate sound power levels less than 20.
4. Pressure given in Pascals, (Pa) and inches of water gauge (in. w.g.).

**Table 7. Radiated Sound Data for Single Duct Supply Air Terminals**(Sound Power Levels, Lw dB, re 10<sup>-12</sup> Watts)

			125 Pa (0.5" W.G.)							250 Pa (1.0" W.G.)							500 Pa (2.0" W.G.)							750 Pa (3.0" W.G.)						
Unit Size	Airflow		Octave Band							Octave Band							Octave Band							Octave Band						
	cfm	L/s	2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7	
4	75	35	37	31	29	21	—	—		37	32	32	25	25	--		37	33	36	30	31	28		37	34	37	32	34	33	
	150	71	51	45	38	29	22	—		51	46	41	33	28	20		51	47	44	38	34	29		51	47	46	40	38	34	
	225	106	59	53	43	34	25	—		59	54	46	38	31	20		59	55	49	42	37	29		59	55	51	45	40	34	
	280	132	63	57	46	36	26	—		63	58	49	40	32	20		63	59	52	45	38	29		63	60	54	47	42	34	
6	125	59	41	33	31	27	23	—		44	37	35	31	29	25		47	41	38	36	35	33		48	44	40	38	38	38	
	250	118	50	43	39	33	27	—		52	47	43	37	32	26		55	52	46	42	38	35		57	54	48	44	42	40	
	375	177	55	49	44	37	29	—		57	53	47	41	34	27		60	58	51	45	40	35		62	60	53	47	44	40	
	500	236	58	53	47	39	30	—		61	58	51	43	36	28		64	62	54	48	42	36		65	64	56	50	45	41	
	630	297	61	57	50	41	31	—		64	61	53	45	37	28		66	65	57	50	43	37		68	68	59	52	46	41	
8	175	83	42	32	29	24	—	—		45	37	34	30	24	--		48	42	40	35	31	25		49	45	43	38	34	29	
	375	177	51	40	36	31	24	—		54	46	42	36	31	25		57	51	47	42	37	32		58	54	50	45	41	35	
	575	271	56	45	41	35	28	23		59	51	46	40	34	29		62	56	52	46	41	35		63	59	55	49	44	39	
	775	366	59	49	44	38	31	25		62	54	49	43	37	31		65	59	55	48	43	38		67	62	58	51	47	42	
	975	460	62	52	46	40	33	27		65	57	51	45	39	33		68	62	57	50	45	40		70	65	60	53	49	43	
	1115	526	64	53	47	41	34	28		67	58	53	46	40	34		70	63	58	51	46	41		71	66	61	55	50	45	
10	250	118	41	31	33	28	22	—		45	36	40	34	29	25		49	42	46	40	36	32		51	45	50	43	40	36	
	550	260	49	39	38	32	27	21		53	45	45	38	33	28		56	50	51	44	40	35		59	54	55	48	44	39	
	850	401	53	43	41	35	29	23		57	49	48	41	36	30		61	55	54	47	42	37		63	58	58	50	46	41	
	1150	543	56	47	43	36	30	24		60	52	50	42	37	31		63	58	56	49	44	38		66	61	60	52	48	42	
	1450	684	58	49	45	38	32	25		62	55	51	44	38	32		66	60	58	50	45	39		68	64	61	53	49	43	
	1745	824	60	51	46	39	33	25		64	57	53	45	39	32		67	62	59	51	46	40		70	66	63	55	50	44	
12	350	165	37	34	36	27	--	--		42	40	43	33	26	23		47	45	49	38	32	30		50	49	52	42	35	33	
	850	401	45	42	42	34	28	22		50	48	49	40	34	29		55	53	55	45	40	35		58	57	58	49	43	39	
	1350	637	50	46	45	37	32	25		55	52	52	43	38	31		60	58	58	49	44	38		63	61	61	52	47	41	
	1850	873	53	49	48	40	35	27		58	55	54	46	40	33		63	60	60	51	46	40		66	64	64	55	50	43	
	2350	1109	55	51	49	42	37	28		60	57	55	48	43	35		65	63	62	53	48	41		68	66	65	57	52	45	
	2515	1187	56	52	50	42	37	29		61	57	56	48	43	35		66	63	62	54	49	41		69	66	66	57	53	45	

**Table 7. Radiated Sound Data for Single Duct Supply Air Terminals**

(Sound Power Levels, Lw dB, re 10<sup>-12</sup> Watts)

			125 Pa (0.5" W.G.)							250 Pa (1.0" W.G.)							500 Pa (2.0" W.G.)							750 Pa (3.0" W.G.)						
Unit Size	Airflow		Octave Band							Octave Band							Octave Band							Octave Band						
	cfm	L/s	2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7		2	3	4	5	6	7	
14	500	236	43	37	35	28	22	—		48	43	41	33	27	—		54	50	47	39	32	26		57	53	51	42	35	29	
	1250	590	49	44	42	35	30	21		55	50	48	41	35	27		60	56	54	46	40	33		63	60	58	50	43	37	
	2000	944	52	47	45	39	34	25		58	53	51	44	39	31		63	59	57	50	44	37		67	63	61	53	47	41	
	2750	1298	54	49	47	41	37	28		60	56	54	47	42	34		66	62	60	52	47	40		69	65	63	56	50	43	
	3420	1614	56	51	49	43	39	30		62	57	55	49	44	36		67	63	61	54	49	42		70	67	65	58	51	45	
16	600	283	37	39	32	28	23	—		42	45	37	33	28	26		47	52	43	37	33	33		51	55	46	40	36	37	
	1400	661	45	45	40	36	31	26		51	51	45	40	36	32		56	58	51	45	42	39		59	61	54	48	45	42	
	2200	1038	50	48	44	40	36	29		55	55	49	44	41	35		60	61	55	49	46	42		63	65	58	52	50	46	
	3000	1416	53	50	47	43	39	31		58	57	52	47	44	37		63	63	58	52	49	44		67	67	61	55	53	48	
	3800	1793	55	52	49	45	41	32		60	58	55	49	46	39		66	65	60	54	52	46		69	68	63	57	55	49	
	4470	2110	57	53	50	46	43	34		62	60	56	51	48	40		67	66	62	55	53	47		70	70	65	58	57	50	
18	1500	708	49	46	40	34	29	23		52	50	44	37	31	26		55	54	48	39	33	29		57	57	50	41	34	31	
	3500	1652	61	56	52	48	44	37		64	60	56	50	46	40		67	65	60	53	48	43		69	67	62	54	49	45	
	5500	2596	68	62	58	55	52	44		71	66	62	58	54	47		74	70	66	60	56	50		75	73	68	62	57	52	
	7500	3540	72	66	63	60	58	49		75	70	67	63	60	52		78	74	70	65	62	56		80	76	73	67	63	57	
	8530	4026	74	67	65	62	60	51		77	71	68	65	62	54		80	76	72	67	64	58		82	78	75	69	65	59	

**Performance Notes:**

1. Tested in accordance with with AHRI 880-2011 and ASHRAE Standard 130-1996: "Methods of Testing for Rating Ducted Air Terminal Units".
2. Airflow given in liters/second L/s; and cubic feet/minute, cfm.
3. Blank spaces "—" indicate sound power levels less than 20.
4. Pressure given in Pascals, (Pa) and inches of water gauge (in. w.g.).

Information in this document is based on specifications believed correct at the time of publication. The right is reserved to make changes as design improvements are introduced. Product or company names mentioned herein may be the trademarks of their respective owners.

© 2017 Siemens Industry, Inc.

**Siemens Industry, Inc.**  
Building Technologies Division  
1000 Deerfield Parkway  
Buffalo Grove, IL 60089-4513  
USA  
+1 847-215-1000

Your feedback is important to us. If you have comments about this document, please send them to [SBT\\_technical.editor.us.sbt@siemens.com](mailto:SBT_technical.editor.us.sbt@siemens.com).

Document No.149-319P25  
Printed in the USA  
**Page 19 of 19**