

BACnet Lab and Pressurized Room Controllers with Off-board Air Modules



Lab Controller Module.



Off-board Air Module 550-819B.

The Laboratory Control Modules (LCMs) and Pressurized Room Controllers (PRCs) have been updated to share the same hardware and enhanced applications on the new PTEC hardware platform. These controllers use the Off-board Air Module (OAM) to measure airflow for standard and custom pressurized room control applications.

These controllers are designed to reside on any BACnet control system.



NOTE:

The 570-8xxPA BACnet laboratory controllers have new 67xx application numbers. New application numbers may require front-end graphics and reporting modifications. Upgrading to the new controllers might, in some rare instances, cause some programming rework.

Lab Controller Module

The LCM operates as an independent, stand-alone DDC controller and can be connected on the Floor Level Network (FLN). The LCM includes the largest physical point count of any FLN device. Not all physical points are used in all applications.

Off-board Air Module

The OAM contains the air velocity sensor (a specialized differential pressure transducer), V/F conversion circuitry and solenoid for auto-zero function. Advanced digital signal processing produces a highly accurate reading of even the noisiest flow signals.

The auto-zero solenoid connects to the air velocity pressure transducer's inlet ports to enable automatic periodic re-calibration. This re-calibration ensures accurate, drift-free airflow measurement. Automatic re-calibration of the differential pressure transducers occurs upon system power-up and when airflows are stable with frequency selectable from 1 to 6 times a day.

**NOTE:**

The redesigned 550-819B Off-board Air Module (OAM) replaces 550-819N for airflow measurement. The 550-819B is easily identifiable by the revision “BA” found on the product bar code label (550-819BBAxxxxxx).

Features

- Communicates using BACnet MS/TP protocol for open communications on BACnet MS/TP networks.
- BTL listed as a B-ASC device.
- Programmable using PPCL.
- Auto-discovery and Auto-addressing over entire MS/TP network. (WCIS 4.0 or later)
- UL864 Listed for Smoke Control.
- Enhanced Room Unit functionality, including room humidity and CO₂ monitoring.
- Enhanced Room Unit functionality, including improved handling of communication losses and thermistor input selections. (570-8xxPA/PKA)
- LCM can be factory mounted on terminal units or Venturi Air Valves, or field mounted in panels located for easier access.
- OAM factory mounted on terminal units or Venturi Air Valves eliminates field installation of airflow signal tubing.
- Control applications available for a variety of airflow control devices, including dampers, terminal units, fans with VFDs and Venturi air valves.
- Control applications using a variety of actuation types including high-speed electronic, low-speed electronic and pneumatic (with transducers).
- Control applications that do not use a general exhaust, does not require a second OAM.
- Airflow sensor is read five times per second, independent of the output device loop time, giving the most accurate reading at all times.
- Airflow sensor is automatically recalibrated periodically to maintain highest accuracy.
- BTU Compensation temperature control application allows tighter control without over-cooling or over-heating during transients (requires discharge temperature sensor).
- Supports the use of wall switch input to change from occupied to unoccupied state.

- Optional room pressurization alarm output to notify laboratory occupants.
- Reports airflow directly in actual CFM (LPS).
- Electrically Erasable Programmable Read Only Memory (EEPROM) used for storing control parameters—no battery backup or re-entry of data required.
- Quick return from power failure without operator intervention that maintains room pressure relationship.
- Maintains room pressurization during transient conditions.
- Plenum rated controller.
- User-adjustable offset for the calibration of room temperature reading when required for validation purposes. See *Application Information*.

Room Sensor/Room Unit

The room sensor connection to the controller board consists of a quick-connect RJ-11 jack. This streamlines installation and reduces controller start-up time.

Combination Temperature, Carbon Dioxide, and Relative Humidity Models

The Series 2200/2300 range of room unit, usable with the LCM/PRCs, includes temperature only or combination temperature/humidity, temperature/CO₂, or temperature/CO₂/humidity models. For these models, all measurement variables—CO₂, temperature and relative humidity values—are passed digitally to the LCM/PRC. This information is passed from the room unit through the RJ-11 cable to the RTS port on the LCM/PRC.

**NOTE:**

A CO₂ power module (product number AQM2200) is also needed for the CO₂ sensor option to function.

BACnet Lab and PRC Specifications

Dimensions	4-1/8" W × 11-1/4" L × 1-1/2" H
Weight	Approx. 3 lbs (1.35 kg)
Controlled Temperature Accuracy, Heating or Cooling	±1.5°F (0.9°C)

Power Requirements

Operating Range	24 Vac +/-20%, 50 or 60 Hz
Power Consumption	7 VA (plus 12 VA per DO)

Inputs

Analog	1 room temperature sensor (10K thermistor) 2 air velocity sensors (only for OAM inputs) 1 setpoint (optional at RTS) 1 auxiliary temperature sensor (10K (default)/100K thermistor) 2 selectable 0-10 Vdc/4-20 mA
Digital	2 dry contacts

Outputs

Analog	3 0-10 Vdc
Digital	8 DO 24 Vac optically isolated solid state switches @ 0.5 amp 1 DO dedicated to AZ function

Airflow Sensing and Control

OAM Measurement Range Accuracy	0 to 5600 fpm (0 to 26 m/s) 3.5% reading maximum error from velocity pressure of 0.023"WC(5 Pa)
Controller Temperature Accuracy	± 1.5 F (0.9 C)

Communications

Remote	BACnet MS/TP (EIA 485), 9600 bps to 76800 bps FLN Trunk
Local	WCIS and PTEC Tool

Ambient Conditions

Shipping & Storage Temperature	-13°F to 158°F (-25°C to 70°C)
Operating Temperature	32°F to 122°F (0°C to 50°C)
Humidity Range	5% to 95% rh (non-condensing)

Agency Listings


UL Listing	UL 864, PAZX
cUL Listed	Canadian Standards C22.2 No. 205, PAZX7
FCC Compliance	47 CFR Part 15
BTL Listed	As a B-ASC device

Application Information


New product/application number includes enhanced Room Unit functionality that enables room humidity and CO₂ monitoring as well as Auto-addressing, Auto-discovery and Smoke Control listed controllers (570-8XXPKA).

LCM/P/N	Application	Airflow Control		Temperature Control		Application Notes
		Device	Output Type	Application	Output	
570-804PA 570-804PKA	6750	Venturi	High-speed Modulating	Room Temp Sensor	0-10V	Flow-Tracking, compatible with VAV fume hood control. OCC and UOC states have separate, selectable: >Differential Flow Setpoint >VAV or CAV Temp Control Mode. Room Temperature Offset for single-point calibration.
	6756			BTU Comp [Discharge Temp Req'd]		
570-803PA 570-803PKA	6751	Damper	High-speed 3-state	Room Temp Sensor	0-10V	Flow-Tracking, compatible with VAV fume hood control. OCC and UOC states have separate, selectable: >Differential Flow Setpoint >VAV or CAV Temp Control Mode. Room Temperature Offset for single-point calibration.
	6757			BTU Comp [Discharge Temp Req'd]		
570-802PA 570-802PKA	6752	Venturi	Low-speed Modulating	Room Temp Sensor	0-10V	Flow-Tracking, compatible with CV2 fume hood control. OCC and UOC states have separate, selectable: >Differential Flow Setpoint >VAV or CAV Temp Control Mode. Room Temperature Offset for single-point calibration.
	6758			BTU Comp [Discharge Temp Req'd]		
570-801PA 570-801PKA	6753	Damper	Low-speed 3- state	Room Temp Sensor	0-10V	Flow-Tracking, compatible with CV2 fume hood control. OCC and UOC states have separate, selectable: >Differential Flow Setpoint >VAV or CAV Temp Control Mode. Room Temperature Offset for single-point calibration.
	6759			BTU Comp [Discharge Temp Req'd]		
570-805PA 570-805PKA	6754	Damper supply Venturi exhaust	Low-speed Modulating / Low-speed 3-state	Room Temp Sensor	0-10V	Flow-Tracking, compatible with CV2 fume hood control. OCC and UOC states have separate, selectable: >Differential Flow Setpoint >VAV or CAV Temp Control Mode. Room Temperature Offset for single-point calibration.
	6760			BTU Comp [Discharge Temp Req'd]		

NOTE: Setpoint hardware adapter is required when using 10K duct sensor in place of room temperature sensor.



PRC / P/N	Application	Airflow Control		Temperature Control		Application Notes
		Device	Output Type	Application	Output	
570-810PA 570-810PKA	6773	Damper	Low-speed 3-state	Room Temp or Discharge Temp Sequenced with Radiation	REHEAT 3- pos/0-10V (<i>Optional</i>) RADIATION 0-10V	Flow-Tracking, NO FH FLOW INPUT. Separate Heating & Cooling Setpoints Two pressurization states. Room Temperature Offset for single-point calibration and SECURE MODE for Part 11 compliance solution.
570-811PA 570-811PKA	6761	Various	Low-speed 3- state Or Modulating	Discharge Temp	REHEAT 0-10V	"Cascade" Control of Room Pressure by Resetting Flow-Tracking Differential. Room Temperature Offset for single-point calibration and SECURE MODE for Part 11 compliance solution.



Product Ordering

Description	Product Part Number
BACnet Lab Controller Module	570-8.XXPA
BACnet Smoke Control Listed Controller Module	570-8.XXPKA
Off-board Air Module	550-819B
Single Duct Supply Terminal	LGSn....n
Dual Duct Supply Terminal	LGDn....n
Exhaust Terminal	LGEEn....n
Airflow Measurement Station	LGFn....n
Venturi Air Valve – Constant Volume – Variable Volume – Zero Leakage Shut-Off	AVCn....n AVVn....n AVZn....n
Venturi Air Valve Accessories	AVAn....n
Laboratory Electronic Actuator	GNP191.1P
TEC Duct Sensor Setpoint Adapter Kit	540-656

Document Information

Description	Product Part Number
Venturi Air Valves	149-425
Conical Venturi Air Valve for Critical Environments	149-524
Venturi Air Valve Accessories	149-495
Laboratory Room Single Duct Supply Air Terminal	149-319
Laboratory Exhaust Air Terminal	149-320
Laboratory Room Dual Duct Supply Air Terminal	149-338
Laboratory Airflow Station	149-317
Laboratory Electronic Actuator Submittal Sheet	155-771

Information in this document is based on specifications believed correct at the time of publication. The right is reserved to make changes as design improvements are introduced. Product or company names mentioned herein may be the trademarks of their respective owners.

© 2015 Siemens Industry, Inc.

Siemens Industry, Inc.
Building Technologies Division
1000 Deerfield Parkway
Buffalo Grove, IL 60089-4513
USA
+1 847-215-1000

Your feedback is important to us. If you have comments about this document, please send them to SBT_technical.editor.us.sbt@siemens.com.

Document No. 149-855
Printed in the USA
Page 6 of 6